

SECURE TRACK ELD

User Guide

Complete Guide to Using the Secure Track ELD System

Table of Contents

ELD Device Setup	3
Login & ELD Connection	4
Shipping & Change Equipmet	5
DVIR	6
Duty status & Driver Status	7
Logs Dashboard & Certification	8
App menu and Driver profile	9
Roadside Inspection	10
Transfer logs to FMCSA & Co-Driver login	11
Personal use	12
Yard move	13
Data Diagnostic/Malfunctions Event	14




ELD Device Setup

Step 1

Ensure that your vehicle's engine is turned OFF. If it is currently running, please switch it off and turn the ignition key to the 'Off' position before connecting the ELD device.

Step 2

Find the diagnostic port inside your vehicle. It's usually located in one of these places: under the left side of the dashboard, below the steering wheel, near the driver's seat, or under the driver's seat



Step 3

To connect the ELD, plug it into your vehicle's diagnostic port. Twist the locking ring until it clicks into place. Make sure the ELD is securely connected.

Step 5

Next, turn on the tablet provided by your fleet and open the Secure Track ELD Application.

Step 4

Once plugged in, the device will begin syncing with the engine control module (ECM) and the Secure Track ELD app on your tablet.





Login


- Enter your registered email address in the **Username** field.
- Fill in your password.
- Click login.
- To save your login details for future use, enable the Remember Password option.



ELD Connection



- Tap the red Connect signal button located in the top-right corner.
- Tap the Scan button if no device appears.
- Click on the device name to establish a connection.



- The app will connect to the ELD, and the signal button will turn green.
- Make sure the device is connected in the app before departure.




Shipping document



- Open the app menu and tap on Shipping.
- Enter all required shipping details, then tap Save to continue.

Change Equipment




- Tap the vehicle icon beside your name.
- Tap the vehicle name and select your vehicle.
- Tap on the trailer name and choose the correct trailer.
- Tap the Save button to confirm your selection.



DVIR






- Press the DVIR tab at the bottom panel.
- Select the DVIR form and click Inspect to start the inspection.
- Mark all inspection points, then press Finish.
- Choose the vehicle's condition
- Sign the report and press Finish DVIR.
- Click Save to complete the inspection.



Duty Status



- Press the Status button.
- Select your current duty status from the list.
- Your odometer and location will be filled in automatically.
- Press the save button.


Driving Status



• The system will change the status to 'Driving' and display complete information.



Logs Dashboard



- Open Logs from the bottom menu.
- Logs of current day will appear
- Select another date to view logs.


Certification



- Click on the certify button on the top right corner.
- Click certify and save data.




App Menu



- Click on the hamburger icon on the left corner.
- Menu options will appear.


Driver Profile




- Click More options in the menu bar.
- Select settings.
- Tap profile to check data.



Roadside Inspection




- Tap the menu icon on the left.
- Select FMCSA.
- Tap Start Review.
- Give the device to the officer for inspection



Click on data transfer




Transfer logs to FMCSA



- Add a comment in the text box.
- Click Transfer to send the report.


Co-Driver




- Open the left side menu.
- Tap Co-driver Login.
- Enter the username and password for the co-driver.
- Press the Login button.
- Again, open the left side menu.
- Select Switch Co-driver.
- Tap View or Make Driver, depending on the action needed.
- Enter your password to confirm and complete the switch.



Personal Use




• Tap on the Status button.




- Select the checkbox for Personal Use under the duty status.
- Enter note
- Press save button.



Yard Move




• Tap the Status button.



- Check the Yard Move box below the duty status options.
- Enter a note
- Press the Save button.




Data Diagnostic Event



- 'D' icon at the top will start blinking.
- Tap the blinking 'D' icon to open it.
- A list of events will appear on the screen.
- Tap an event to view its details.

Malfunctions Event



- The 'M' icon at the top will start blinking.
- Tap the blinking 'M' icon to open it.
- A list of events will appear.
- Tap any event to view its details.